

ScanMaker i2400

Super Slim SOHO Scanner



CIS

2400
DPI

6
Buttons

40 mm
Super Slim

8 sec
A4 Color

USB
Bus
Power

ScanMaker i2400

Six Smart-Touch Function Buttons



Scans the image and directly links to your assigned photo-sharing website.



Scans the image and saves it in the Adobe Acrobat PDF format.



From paper to digital in one easy step.



Stay in touch! Email photos to family and friends.



Make color copies of your favorite photos or prints.



Instantly scans to file or an application.

Power up Your Movability!

The ScanMaker i2400 can be simply powered by USB cable, without external power supply needed. As being one member of green product family, ScanMaker i2400 not only consumes less energy, but also makes your memories fresh as ever! Just connect it via USB port of your PC or laptop, and you can carry and use it almost anywhere, anytime!



Super-slim and lightweight design!

Microtek's exclusive ColoRescue™ restores faded color

The ScanMaker i2400 is equipped with Microtek's exclusive ColoRescue technology, which can bring faded colors back to life for more vibrant images. With just a single click, you can recover old and dim photos back to their original brilliance.



Dual OS Systems Supported

No matter you are a Windows advocator or a Mac addict, you can use ScanMaker i2400 in either of two OS systems as your preference. With brand new developed ScanWizard EZ (PC) and ScanPotter (Mac) software programs, you can find variety scanning solutions for your scans. Both novices and experienced users can find them productive and easy to use.



Specifications

Scanner Type

Flatbed color scanner

Image Sensor

CIS

Light Source

LED

Color Modes

48-bit color, 16-bit grayscale, 1-bit b&w

Scanning Method

Color, grayscale, and black-and-white in a single scanning pass

Optical Resolution

2400 x 4800 dpi

Scanning Speed

8 sec, at 300 dpi, A4 /color

Scanning Area

8.5" x 11.7" / 216 mm x 297 mm

Interface

Hi-Speed USB 2.0

Dimensions (L x W x H)

16.14" x 10.83" x 1.57" / 410 mm x 275 mm x 40 mm

Weight

3.83 lbs. / 1.74kg

Environment

Operating temperature: 50° to 104°F (10° to 40°C)

Relative humidity: 20% to 80%

System Requirements

PC

- CD/DVD-ROM drive (for installing software)
- Color display with 24-bit color output capability
- 512 MB RAM or more
- Pentium IV PC or higher with USB 2.0 port
- Windows XP, Vista, 7 or 8

Mac

- CD/DVD-ROM drive (for installing software)
- Color display with 24-bit color output capability
- 1 GB of RAM or more
- Intel-Based Mac computer with built-in USB port
- Mac OS X 10.6 or later

Included Software

- Microtek® ScanWizard™ EZ (PC)
- Microtek® ScanPotter (Mac)
- ABBYY FineReader® Sprint OCR (PC/Mac)
- InterVideo MediaOne Gallery™ (PC)
- Adobe® Acrobat® Reader (PC)



MICROTEK INTERNATIONAL, INC.

No. 6 Industry East Road 3, Science-Based Industrial Park, Hsinchu 300, Taiwan

Tel: 886-3-577-2155 Fax: 886-3-577-2598 <http://www.microtek.com>

© 2013 Microtek. Microtek, ScanMaker, ArtixScan and ScanWizard are trademarks or registered trademarks of Microtek International, Inc. All other brands, product names and logos herein are trademarks or registered trademarks of their respective holders. Specifications, software bundles and accessories are subject to change without notice. Delivery of technical support services subject to change without notice. Not responsible for typographical errors. © 2011 Ingram Publishing. 20131230

For more details on product, please contact your local Microtek sales or dealers.

MICROTEK
SCAN THE WORLD