

ScanMaker i460

A4 Scanner for SOHO and Home Users



CCD

4800
DPI

48-bit
Color

Warm-up
Free

LED

A4
Size

6
Buttons

Optional
LightLid

ScanMaker i460

6 Smart-Touch Function Buttons



WEB: Scan the image and directly links to your assigned photo-sharing website.



PDF: Scans the image and saves it in the Adobe Acrobat PDF format.



OCR: From paper to digital in one easy step.



E-MAIL: Stay in touch! Email photos to family and friends.



COPY: Make color copies of your favorite photos or prints.



SCAN: Instantly scans to file or an application.

Scanning A4-sized Documents in Just 6 Seconds



The ScanMaker i460 can handle scanning of documents very fast, which needs only 6 seconds to finish a scan of A4-sized color document.

Therefore, there is no doubt that the ScanMaker i460 can be listed as a treasure and rare product which can have both top output quality and fast scanning speed.

Energy-saving LED Light Source

Adopting LEDs as the light source, when the scanner is detected by the system, there is no need to warm up before carrying out the scan, which boots your productivity and reduces energy costs amazingly. With its stable performance, the image quality will remain consistent even after used for a certain period of time.

Microtek's Exclusive ColoRescue™ Restores Faded Color

Microtek's ColoRescue™ is a color restoration solution, which can restore faded colors in both photos and film, bringing hues back to their original luster and brilliance for vibrant images. ColoRescue's one-click, automatic color recovery process is simple and straightforward, involving no learning curve or hassle.



User Friendly and Easy Access Software

With brand new developed ScanWizard EZ (PC) and ScanPotter (Mac) scanner software, you can find variety scanning solutions for your scans. Both novices and experienced scanner users can find them productive and easy to use.



OPTIONAL

35mm Film Adapter



Now you can scan filmstrips or up to 4 slides at a time. Get those boxes filled with vacation slides out of the closet, and archive all of your old slides and filmstrips quickly and easily! Using Microtek's patented LightLid 35 IV film adapter, you simply insert your film, place it on the bed and scan.

Specifications

Scanner Type

Desktop color flatbed scanner

Image Sensor

CCD

Light Source

LED

Color Modes

48-bit color, 16-bit grayscale, 1-bit b&w

Scanning Method

Color, grayscale, and black-and-white in a single scanning pass

Optical Resolution

4800 x 9600 dpi

Scanning Speed

6 sec, at 300 dpi, A4/color

Scanning Area

Reflective: 8.5" x 11.7" (216 mm x 297 mm)

Transparent: 0.9" x 7.8" (24.5 mm x 200 mm)

Interface

Hi-Speed USB 2.0

Dimensions (L x W x H)

17.48" x 10.98" x 2.13" (444 mm x 279 mm x 54 mm)

Weight

5.94 lbs. / 2.7 kg

Environment

Operating temperature: 50° to 104°F (10° to 40°C)

Relative humidity: 20% to 85%

System Requirements

PC

- CD/DVD-ROM drive (for installing software)
- Color display with 24-bit color output capability
- 512 MB RAM or more
- Pentium IV PC or higher with USB 2.0 port
- Windows XP, Vista, 7 or 8

Mac

- CD/DVD-ROM drive (for installing software)
- Color display with 24-bit color output capability
- 1 GB of RAM or more
- Intel-Based Mac computer with built-in USB port
- Mac OS X 10.6 or later

Included Software

- Microtek® ScanWizard™ EZ (PC)
- Microtek® ScanPotter (Mac)
- ABBYY FineReader® Sprint OCR (PC/Mac)
- InterVideo MediaOne Gallery™ (PC)
- Adobe® Acrobat® Reader (PC)



MICROTEK INTERNATIONAL, INC.

No. 6 Industry East Road 3, Science-Based Industrial Park, Hsinchu 300, Taiwan

Tel: 886-3-577-2155 Fax: 886-3-577-2598 <http://www.microtek.com>

© 2013 Microtek. Microtek, ScanMaker, ArtixScan and ScanWizard are trademarks or registered trademarks of Microtek International, Inc. All other brands, product names and logos herein are trademarks or registered trademarks of their respective holders. Specifications, software bundles and accessories are subject to change without notice. Delivery of technical support services subject to change without notice. Not responsible for typographical errors. © 2011 Ingram Publishing. 20131230

For more details on product, please contact your local Microtek sales or dealers.

MICROTEK
SCAN THE WORLD